

1995+ Cam Sensor Retrofit Guide

For use with 1995-1997 Distributor from a Mx6,626 or Ford Probe

Will not work with 1993-1994 Distributor

Install Instructions:

1. Completely strip down your distributor of all its components, including the coil. This is what your distributor will look like when its ready for the retrofit parts.



2. Install the coil space filler, you will reuse the existing screws that were removed in step 1. The coil space filler screw holes will only line up one way.
3. Do not over tighten these screws. This will damage the plastic, it only needs to be snugly seated.



4. Install the cam sensor mount plate with screws removed during step 1.



5. Install the cam sensor components that you removed in step 1. The triangle spacer that the rotor pushes onto will need to be ground down as shown in the picture. This can be done in a lathe or with a grinder. Do not remove too much material as the nut will be ruined. This nut is critical to keeping the cam sensor components aligned.



6. Install the Outer Cam Sensor Cover using existing screws from your distributor cap. Your retro fit is complete.



7. Reference Wiring for the Cam Sensor

